


# SHIMANO

STRADIC  A-RB

ST-8000FJ



Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

(1SE458010U)

| Part No. | Description            | Part No. | Description                | Part No. | Description              |
|----------|------------------------|----------|----------------------------|----------|--------------------------|
| RD 0521  | Rotor Nut              | RD10421  | Line Roller Collar         | RD13189  | Ball Bearing             |
| RD 0632  | Screw                  | RD10422  | Line Roller                | RD13274  | Ball Bearing             |
| RD 0647  | Screw                  | RD10423  | Line Roller Bushing        | RD13893  | Drag Washer              |
| RD 0787  | Screw                  | RD10752  | Spring Guide A Support     | RD13894  | Drag Washer              |
| RD 2298  | Spacer                 | RD10790  | Bail Spring                | RD14250  | Line Roller Oil Cap      |
| RD 2409  | Spacer                 | RD11156  | Key Washer                 | RD14802  | Handle Screw Cap         |
| RD 3492  | Screw                  | RD11159  | Bail Spring Guide A        | RD14829  | Drag Click Spring        |
| RD 3503  | Spool Washer           | RD12440  | Screw                      | RD14830  | Screw                    |
| RD 3561  | Screw                  | RD12457  | Oscillating Pawl Cover     | RD14887  | Drag Click               |
| RD 4150  | Screw                  | RD12459  | Oscillating Pawl           | RD14919  | Pinion Gear              |
| RD 4362  | Screw                  | RD12468  | Screw                      | RD14976  | Drag Knob                |
| RD 4680  | Screw                  | RD12889  | Bail Trip Lever            | RD14978  | Spool Support A          |
| RD 4749  | Screw                  | RD12896  | Screw Collar               | RD14979  | Spool Support B          |
| RD 5040  | Screw                  | RD12897  | Bail Hold Support Spacer   | RD14980  | Main Shaft               |
| RD 5690  | Screw                  | RD12898  | Bail Hold Support Shaft    | RD14981  | Line Roller Washer       |
| RD 5841  | Screw                  | RD12900  | Friction Ring              | RD14982  | Line Roller Plate        |
| RD 6192  | Washer                 | RD12902  | Anti-Reverse Cam           | RD14983  | Bail Arm                 |
| RD 6227  | Washer                 | RD12903  | Anti-Reverse Cam Spring    | RD14984  | Rotor                    |
| RD 6395  | Roller Clutch Assembly | RD12904  | Anti-Reverse Lever         | RD14985  | Line Roller Support      |
| RD 6524  | Worm Bushing (rear)    | RD12906  | Worm Bushing (front)       | RD14986  | Bail Assembly            |
| RD 6606  | Screw                  | RD12911  | Oscillating Slider Bushing | RD14987  | Bail Trip Strike         |
| RD 7665  | Screw                  | RD12912  | Oscillating Slider         | RD14988  | Anti-Reverse Lever Cover |
| RD 7919  | Click Spring           | RD12914  | Worm Shaft Retainer        | RD14989  | Drive Gear               |
| RD 7920  | Click Pin              | RD12915  | Worm Shaft                 | RD14990  | Side Cover               |
| RD 7945  | Nut                    | RD12916  | Oscillating Guide          | RD14991  | Handle Assembly          |
| RD 8594  | Eared Washer           | RD12922  | Bail Spring Cover          | RD14992  | Rear Protector           |
| RD 8654  | Drag Washers Retainer  | RD12924  | Bail Hold Support Guard    | RD14993  | Body                     |
| RD 9379  | Screw                  | RD13044  | Oil Cap                    | RD14994  | Spool Assembly           |
| RD10377  | Screw                  | RD13185  | Ball Bearing               | RD15233  | Idle Gear                |
| RD10420  | Bearing Spacer         | RD13188  | Ball Bearing               |          |                          |

(231221)